



Velvet Drive Marine Transmission Service Manual Model 72C

Figure 1. The effect of the number of trials on the number of correct responses. The number of correct responses was significantly higher than the number of incorrect responses in all conditions.

Velvet Drive Marine Transmission Service Manual Model 72C



Garrett Marine Corp., Technical
Division

Hamden, Conn. 06530, U.S.A.
Tel. (203) 282-1000
Telex 980 000 000

© 1975 Garrett

This Service Manual is prepared and illustrated for the 72C drive drive transmission, but it also contains

supplementary information and illustrations which show it to be used for the servicing of the other model

transmissions, A21-25 and A21-2.

Worm Gear



Garrett Marine Corp., Technical
Division, 1000 Main Street, Hamden,
Conn. 06530, U.S.A.
Tel. (203) 282-1000

1000 Main Street, Hamden, Conn. 06530, U.S.A.

TABLE OF CONTENTS

INSTALLATION INSTRUCTIONS AND INFORMATION.....	5
CROSS SECTION ASSEMBLY DRAWINGS.....	8
PARTS DISPLAY AND INFORMATION.....	10
CIRCULATION DIAGRAM.....	12
DESCRIPTION.....	14
INSTALLATION PRECAUTIONS.....	15
Transmission oil cooler.....	15
Control lever position.....	15
Front pump mounting.....	16
LUBRICATION RECOMMENDATIONS.....	16
Oil recommended.....	16
Procedures for filling transmission with oil.....	16
Changing oil.....	16
Procedures for checking oil level.....	16
Oil pressures.....	16
Oil capacity.....	16
TRANSMISSION OPERATION.....	17
Forward.....	17
Neutral.....	17
Reverse.....	17
Shifting.....	17
DISASSEMBLY OF TRANSMISSION.....	18
Oil draining procedure.....	18
Disassembly of valve and spring assembly from transmission.....	18
Removal of front pump assembly.....	18
Disassembly of adapter and reverse clutch piston.....	19
Removal of thrust washers, reverse clutch pressure plate, pressure plate springs, bowl pins and reverse clutch plates.....	19
Disassembly of drive gear and clutch assembly.....	19
Disassembly of forward clutch.....	19
Removal of piston cage and output shaft assembly from trans. case.....	20
Removal of rear bearing.....	20
REASSEMBLY PRECAUTIONS.....	20
INSPECTION AND GENERAL INSTRUCTIONS.....	21
ASSEMBLY OF TRANSMISSION.....	21
Assembling oil seal in bearing retainer.....	21
Installation of the baffle in the transmission case.....	22
Installation of piston cage and output shaft assembly in the trans. case.....	22
Assembly of the forward clutch into the ring gear.....	24
Assembly of forward clutch hub and sealing rings on drive gears.....	27
Assembling drive gear and clutch assembly.....	28
Installation of drive gear and clutch assembly, reverse clutch plate, and reverse clutch pressure plate in transmission case.....	29
Assembly of reverse clutch piston into adapter.....	31
Assembly of adapter and reverse clutch plates onto transmission case.....	32
Assembly of front pump.....	32
Mounting front pump on transmission.....	34
Assembling valve and spring assembly.....	35
Installation of the valve and spring assembly in the trans. case.....	36
Assembly of shift lever.....	37
Installation of oil strainer assembly and oil drain plug into transmission case.....	38
Installation of miscellaneous transmission parts.....	38

EXTRA EQUIPMENT.....	39
Assembly of neutral switch kit.....	39
SPECIAL INFORMATION AND INSTRUCTIONS-MODEL T2C TRANSMISSIONS.....	40
Installation of oil filler cap and dip stick assembly.....	40
Installation of oil strainer assembly and oil drain plug into transmission case.....	40
Installation of breather assembly.....	41
Assembly of front pump.....	41
Mounting front pump on transmission.....	42
Elimination of regulator valve leak.....	44
Drive gear and plug assembly.....	45
Pinion cage and output shaft assembly.....	45
Forward and reverse gear transmission case and backing assembly.....	45
Adaptor cap screws.....	45
SPECIAL INFORMATION AND INSTRUCTIONS-MODEL T2 TRANSMISSIONS.....	46
Installation of breather assembly.....	46
Assembly of front pump.....	46
Selection of reverse clutch plates.....	46
Drive gear and plug assembly.....	46
Assembly of shift lever.....	47
Selection of output shaft coupling.....	47
Cooler return to transmission.....	47
SPECIAL SERVICE KITS.....	48
Planetary service kits.....	48
Oil collector ring kit.....	48
Transmission case service backing kit.....	48
Output shaft backing kit.....	48
Clutch pack kits.....	48
Small parts repair kits.....	48
TROUBLE SHOOTING CHART.....	52
TORQUE SPECIFICATIONS.....	54
ASSEMBLY TOOL DRAWINGS.....	55


IDENTIFICATION OF POLYESTER BLENDED WITH POLYURETHANE BY THE FT-IR AND TGA

[illegible]


- g) **Force interaction** is identified when the observer is standing in front of the transmitter, being the position the sensor located around the transmitter. The error is caused by the distance between the sensor and the input shaft. If the distance is small, the error is small. The error is caused by the distance between the sensor and the input shaft. If the distance is small, the error is small. The error is caused by the distance between the sensor and the input shaft. If the distance is small, the error is small.

DATA SOURCE: Mapping is done for all non-fiber images. If a 1 relaxation ratio is the only difference between 2 scans, the algorithm goes on and another scan in 2 ratio is different than the last used 1:0.5 ratio is then 0.5 relaxation ratio, therefore, starting the search for non-saturations are performed on these iterations. The search is done until the search for non-saturations is stopped automatically at 0.5:1 ratio.

- [illegible]




10. *Journal of the American Medical Association*, 279:1225-1230 (1997).




THIS SECTION REPRESENTS PART
OF THE ENGINE AS IT IS
TO BE USED IN THE
LIFE OF THE ENGINE. THE
PARTS TO BE REPLACED ARE
SHOWN.

Fig. 1. Cross section of engine with 400 mm stroke.



THIS SECTION REPLACES PART 101
 WHICH WAS IN THE 1954 EDITION OF
 THIS DRAWING. THE PARTS LISTED IN
 THE LIST OF PARTS IN THE 1954 EDITION
 OF THIS DRAWING ARE THE PARTS
 LISTED IN THE 1954 EDITION OF
 THIS DRAWING.

Fig. 1. Cross section of motor and pump assembly.




200-hp, 1000-rpm motor. The motor is shown in cross-section, revealing the internal components. The motor is shown in cross-section, revealing the internal components. The motor is shown in cross-section, revealing the internal components.

**TEST SPECIFICATIONS FOR FIBER, 100-UM, IN
100-UM-BUNDLE MODE (PARTIAL BUNDLE) (Part 1 of 2)**

Fiber type	RECEIVED, μW				EMITTED, μW			
	100		1.00		100		1.00	
	min	max	min	max	min	max	min	max
100	—	—	—	—	20	—	100.0	—
100- 1,000	1.00	1.00	100.0	100.0	1.00	1.00	100.0	100.0
1,000	—	—	—	—	1.00	1.00	100.0	100.0



**TEST SPECIFICATIONS FOR FIBER, 10-UM, IN
100-UM-BUNDLE MODE (PARTIAL BUNDLE) (Part 1 of 2)**

Fiber type	RECEIVED, μW				EMITTED, μW			
	100		1.00		100		1.00	
	min	max	min	max	min	max	min	max
100	—	—	—	—	10	—	100.0	—
100- 1,000	10	100	100.0	100.0	10	1.00	100.0	100.0
1,000	—	—	—	—	100	1.00	100.0	100.0



Item no.	Part No.	Description	Unit
1	4-111111	Wash water tank	1
2	4-111111-1	Wash water tank (111111)	1
3	4-111111-2	Wash water tank (111111)	1
4	4-111111-3	Wash water tank (111111)	1
5	4-111111-4	Wash water tank (111111)	1
6	4-111111-5	Wash water tank (111111)	1
7	4-111111-6	Wash water tank (111111)	1
8	4-111111-7	Wash water tank (111111)	1
9	4-111111-8	Wash water tank (111111)	1
10	4-111111-9	Wash water tank (111111)	1
11	4-111111-10	Wash water tank (111111)	1
12	4-111111-11	Wash water tank (111111)	1
13	4-111111-12	Wash water tank (111111)	1
14	4-111111-13	Wash water tank (111111)	1
15	4-111111-14	Wash water tank (111111)	1
16	4-111111-15	Wash water tank (111111)	1
17	4-111111-16	Wash water tank (111111)	1
18	4-111111-17	Wash water tank (111111)	1
19	4-111111-18	Wash water tank (111111)	1
20	4-111111-19	Wash water tank (111111)	1
21	4-111111-20	Wash water tank (111111)	1
22	4-111111-21	Wash water tank (111111)	1
23	4-111111-22	Wash water tank (111111)	1
24	4-111111-23	Wash water tank (111111)	1
25	4-111111-24	Wash water tank (111111)	1
26	4-111111-25	Wash water tank (111111)	1
27	4-111111-26	Wash water tank (111111)	1
28	4-111111-27	Wash water tank (111111)	1
29	4-111111-28	Wash water tank (111111)	1
30	4-111111-29	Wash water tank (111111)	1
31	4-111111-30	Wash water tank (111111)	1
32	4-111111-31	Wash water tank (111111)	1
33	4-111111-32	Wash water tank (111111)	1
34	4-111111-33	Wash water tank (111111)	1
35	4-111111-34	Wash water tank (111111)	1
36	4-111111-35	Wash water tank (111111)	1
37	4-111111-36	Wash water tank (111111)	1
38	4-111111-37	Wash water tank (111111)	1
39	4-111111-38	Wash water tank (111111)	1
40	4-111111-39	Wash water tank (111111)	1
41	4-111111-40	Wash water tank (111111)	1
42	4-111111-41	Wash water tank (111111)	1
43	4-111111-42	Wash water tank (111111)	1
44	4-111111-43	Wash water tank (111111)	1
45	4-111111-44	Wash water tank (111111)	1
46	4-111111-45	Wash water tank (111111)	1
47	4-111111-46	Wash water tank (111111)	1
48	4-111111-47	Wash water tank (111111)	1
49	4-111111-48	Wash water tank (111111)	1
50	4-111111-49	Wash water tank (111111)	1
51	4-111111-50	Wash water tank (111111)	1
52	4-111111-51	Wash water tank (111111)	1
53	4-111111-52	Wash water tank (111111)	1
54	4-111111-53	Wash water tank (111111)	1
55	4-111111-54	Wash water tank (111111)	1
56	4-111111-55	Wash water tank (111111)	1
57	4-111111-56	Wash water tank (111111)	1
58	4-111111-57	Wash water tank (111111)	1
59	4-111111-58	Wash water tank (111111)	1
60	4-111111-59	Wash water tank (111111)	1
61	4-111111-60	Wash water tank (111111)	1
62	4-111111-61	Wash water tank (111111)	1
63	4-111111-62	Wash water tank (111111)	1
64	4-111111-63	Wash water tank (111111)	1
65	4-111111-64	Wash water tank (111111)	1
66	4-111111-65	Wash water tank (111111)	1
67	4-111111-66	Wash water tank (111111)	1
68	4-111111-67	Wash water tank (111111)	1
69	4-111111-68	Wash water tank (111111)	1
70	4-111111-69	Wash water tank (111111)	1
71	4-111111-70	Wash water tank (111111)	1
72	4-111111-71	Wash water tank (111111)	1
73	4-111111-72	Wash water tank (111111)	1
74	4-111111-73	Wash water tank (111111)	1
75	4-111111-74	Wash water tank (111111)	1
76	4-111111-75	Wash water tank (111111)	1
77	4-111111-76	Wash water tank (111111)	1
78	4-111111-77	Wash water tank (111111)	1
79	4-111111-78	Wash water tank (111111)	1
80	4-111111-79	Wash water tank (111111)	1

[illegible]



DESCRIPTION



Fig. 10. External view of M1-T20

This manual is prepared primarily for the Model T20. When drive transmissions. However, all additional explanatory descriptions and illustrations are included to allow it to be used for the Model T2 transmission.

The material in this manual is also used in conjunction with the proper reference gear manuals for covering all T2, T20, T2C and T20B reduction gear transmissions.



Fig. 11. External view of M1-T2

The following list identifies the important features of the various model transmissions in (Fig. 10 and Fig. 11):

- A. Oil Filler Cap & Dipstick Assembly
- B. Oil Venturi Air Operator
- C. Oil Filler Plug Gasket
- D. Oil Drain Plug
- E. Oil Plug
- F. Mounting Pad & Mounting Bolt. Bolts
- G. Mounting Pad
- H. Mounting Pad Flange
- I. Mounting Pad
- J. Mounting Pad
- K. Mounting Pad
- L. Mounting Pad
- M. Mounting Pad

The following are the identification markings for the Mounting Pad (M1-T20) and M1-T20B Series Transmissions.



TYPE	NAME OF IDENTIFIER	TYPE	NAME OF IDENTIFIER	TYPE	TYPE	NAME OF IDENTIFIER
M1-T20	CLUBBING	M1-T20B	CLUBBING	101	101-101	101
M1-T20	CLUBBING	M1-T20B	CLUBBING	101	101-101	101
M1-T20	CLUBBING	M1-T20B	CLUBBING	101	101-101	101

The text of this manual is intended to be used in other areas than those of the text of this manual.

*REVISIONS TO THIS MANUAL ARE INDICATED BY THE FOLLOWING:

The transmission consists of a planetary gear set, a forward clutch, a reverse clutch, an oil pump, and a pressure regulator and return control valve. All of these are contained in a cast iron housing along with secondary shafts and components, to provide forward, reverse and neutral operation. A driven drive shaft is used for all forward operation. In reverse the speed of the output shaft is reduced by a 1.38 ratio from that of the input shaft speed, and is in the opposite direction. Reverse gearing is used to provide reverse operation, then can be disengaged with spur gearing.

The transmission is free shifting to give the boat operator complete control of the vessel. Shifting is accomplished by the force and aft movement of the shift lever. (Figs. 15 & 11). This movement operates the control valve and directs oil under controlled pressure to the required channels.

Oil pressure is provided by the constant type pump, the drive gear of which is keyed to the drive shaft and operates as transmission input speed to provide constant oil to the pressure regulator.

From the regulator valve the oil is directed through the proper circuits to the bearings and anti-friction bearings requiring lubrication. A line of lubricant is present at the required points whenever the drive pump is working and it should be noted that supply is positive in forward, neutral and reverse conditions.

The unit has seals to prevent leakage of oil.

Both the input and output shafts are sealed, with the input shaft optional for the installation of a drive flange, and the output shafts provided with a flange for connecting to the propeller shaft.

INSTALLATION PRECAUTIONS

TRAWNERSHIP OIL COOLER

The oil cooler must be properly connected to the transmission before the engine is cranked or started. Failure to properly connect the oil cooler will result in the following one of the forward clutch problems due to over pressurization: No Warranty claims due to this type failure will be allowed as this is the responsibility of the Boat Builder, Engine Manufacturer or Conversion Engine Manufacturer.

A caution of sufficient oil should be used to ensure that the maximum oil temperature of the transmission will not exceed 150°F. Failure to provide proper cooling may result in damage to the transmission from insufficient oil flow and pressure if the transmission is operated at temperatures above the maximum recommended.

The proper oil cooler inlet and outlet connections are shown in (Figs. 1, 10, & 11).

Although the type of cooler used is optional, a selection of three different sized coolers are manufactured by Warner Gear for installation with these transmissions. Information regarding these coolers may be required upon request from your local dealer.

CONTROL LEVER POSITION

The position of the control lever on transmission shaft in forward should be shifted to the point where it covers the letter "F" on the main casting, and is locked in the proper position by the poppet ball. The Warranty is cancelled if the shaft lever poppet spring and/or ball is permanently misused, or if the control lever is changed in any manner, or tampered with, or if linkage between remote control and transmission shift lever does not have sufficient travel in both directions. This does not apply to transmissions equipped with Warner Gear electrical shift control.

FRONT PUMP MOUNTING

Before mounting the transmission on the engine be sure that the pump is correctly installed. Orient the pump mounting bolt holes and arrows indicating

direction of rotation to correspond with the direction of rotation required for the engine. If the pump is not installed for the proper rotation the pump will not produce oil pressure to operate the transmission when engine is started.

LUBRICATION RECOMMENDATIONS

TRANSMISSION FLUID

Cummins' Type F, and other hydraulic transmission fluids which meet the Detroit Diesel Allison Type F3 specifications are recommended for use in all Detroit Diesel® engine transmissions.

Lubricating oils which are recommended for use in diesel engines and also meet Detroit Diesel Allison Type F3 specifications may be used if the engine speed does not exceed 2000 RPM, 540-700 is preferred, 540 RPM acceptable if high operating temperatures are to be encountered. Multigrade oils such as 15W-40 are acceptable. The top-dressing oil viscosity table is the SAE J300 service class "CD." The second choice would be an oil which falls in the SAE J300 service class "CE."

The equivalent SAE oil grades are:

- CD SAE 15W-40
- CE SAE 15W-40

The new CE specifications were developed by Detroit Diesel Allison Division of General Motors to realize the requirements of an oil suitable for use in their heavy duty hydraulic automatic and powershift transmissions. The oil companies should be able to provide information on the suitability of their product lines in a given application.

FILLING THE TRANSMISSION

NOTE: Be sure the cooler is properly installed and the transmission contains oil before cranking or starting engine.

Fill the transmission prior to starting the engine and immediately after the engine starts add oil to maintain the oil level near the full mark. Fill carefully filling the transmission maintains the possibility of pumping air into the hydraulic system.

CHANGING THE OIL LEVEL

External cooler circuit variations, such as length of lines, size of lines, cooler size, and the position in which the cooler is mounted all affect the amount of

refrigerative ability transmission. Oil will sometimes drain back into the transmission from the cooler and cooler lines, when cooler and lines are improperly installed. It is important that oil level checks on all new installations be made immediately after the engine has been shut off and before the oil has had a chance to drain back.

Oil, which drains from the oil cooler and cooler lines, will cause the oil level in the transmission, oil level for such installations, which is to be checked prior to starting the engine, can be established by properly filling the oil cooler above engine installation drain back.

The dipstick assembly need not be inserted into the case to determine the oil level in most oils, be inserted inside centered the case on dry state on the surface surrounding the oil filler hole.

The transmission should be checked periodically to assure proper oil level, and oil should be added if necessary.

CHANGING OIL

It is recommended that the transmission oil be changed once each season. After draining from the unit, the translatable oil stream should be thoroughly cleaned before refilling the transmission with the recommended oil.

OIL PRESSURES

Transmission line pressure should be between 150-160 PSI at engine speeds between 600 and 2000 RPM at normal operating temperatures of 100-110°F.

When operating the transmission at low temperatures or excessive service pressures of 200-250 PSI may be obtained.

A maximum transmission oil temperature of 160°F is recommended.

OIL CAPACITY

TRANSMISSION MODEL	TRANSMISSION OIL CAPACITY (QUARTS)	
	LEVEL	1" HOLES IN
44T1-FC & CR	2.1	1.1

***NOTE: DOES NOT INCLUDE CAPACITY NEEDED FOR TRANSMISSION COOLER AND OIL LINES.**

TRANSMISSION — OPERATION

FORWARD

Move the transmission shift lever to the extreme forward position where the spring-loaded ball covers the slanted hole in the side of the shift lever and properly locates it in the "forward" position, (Fig. 11). With the shift lever so located, oil at regulated pressure flows from the control valve into porting in the transmission case, output shaft, drive gear, and then into the casing behind the piston in the forward clutch cylinder. The resulting movement of the forward clutch piston and the force action of the clutch spring forces the multiple disks of the forward clutch together and, with the aid of the forward clutch link, locks the input shaft to the ring gear. This in turn prevents rotation of the planetary pinions about their own axis and when locked the input shafts, ring gear and output shafts together, causing them to rotate as a solid concentric coupling. In this way, input shaft speed and direction of rotation are synchronized directly to the output shaft.

NEUTRAL

Move the transmission shift lever to the center position where the spring-loaded ball covers the slanted hole in the side of the shift lever and properly locates it in the "neutral" position, (Fig. 12). With the shift lever so located, flow of pressurized oil to the clutches is blocked as the control valve, The clutches are also vented, to a different portion of the control valve, to the vent area inside the transmission case and thus free-running operation is insured.

REVERSE

Move the transmission shift lever to the extreme rearward position where the spring-loaded ball covers the slanted hole in the side of the shift lever



Fig. 12. 400-4000 SHAFT, Lower Port View.

and properly locates it in the "reverse" position, (Fig. 13). With the shift lever so located, oil at regulated pressure flows from the control valve into porting in the transmission case, through back to the adapter and into the reverse clutch cavity. The resulting movement of the reverse clutch piston and the reverse clutch pressure plate locks the reverse clutch plate to the transmission case. The stationary reverse clutch plate, through splined connection, then prevents rotation of the ring gear. With the ring gear held and the new gear rotating at input speed, the pinions of the compound planetary gearbox are free to rotate about their own axis and reverse the direction of rotation of the pinion carrier and output shafts.

SHIFTING

Except in an emergency, shift from forward to reverse below high idle engine speeds (approximately 1000 RPM). This will prevent damage or stress of the mating gear which might occur when in early reverse.

DISASSEMBLY OF TRANSMISSION

NOTE: From drain procedure should not begin until the transmission is jacked and work area has been thoroughly cleaned.

Oil Draining Procedure

1. Remove oil filler plug located below the shaft cover on rear left side of transmission case.
2. If space permits, place container having approximately three (3) quart capacity under drain plug, located as shown in (Fig. 10). Remove the drain plug and allow return tube assembly, except for the opening with a container tank, and remove the return assembly. (Fig. 11). Allow oil to drain from pan.

Removal of Valve and Spring Assembly from Transmission

1. Remove valve (1) low head ball, lockwashers, valve cover and valve cover gasket, as shown in (Fig. 11).
2. Remove shaft lever and associated parts. (Fig. 12).
3. Tap with axle hammer on mounted threaded shaft, until shaft/shaft lever was mounted, and roll valve

and spring assembly out of case from right side. (Fig. 13).

4. Place valve and spring assembly in a suitable holder. (Fig. 14). Depress the valve spring retainer and valve spring until the top ring is free to be removed. The compressors of the valve and spring assembly can now be removed in the order shown in (Fig. 15).

NOTE: The internal valve assembly can also be disconnected by using an airer press which suitable tools as shown in (Fig. 16).

Removal of Front Pump Assembly

1. Remove the three (3) front pump assembly bolts. (Fig. 17). Place a protective covering over openings to prevent damage to seal lip, and lift pump assembly upward up and over the protruding input shaft. (Fig. 18).
2. Remove pump drive gear, front gear gasket, and Bendix hub. (Fig. 19).

NOTE: For different pump assemblies are used, this includes a locking plate which must be removed before the gears are exposed. For additional information and descriptions see pages 10 and 41-42.

3. For the pump assembly with the locking plate, remove the one (1) front housing machine screw. (Fig. 20) and lift locking plate to expose gears.
4. With gears in position for proper selection of gear during reassembly. (Figs. 41 and 42). (Figs. 43 and 44) show view of the millimeter front pump gears when completely disassembled.



Fig. 11 Draining Transmission Oil

DISASSEMBLY OF DRIFT AND REVERSE CLUTCH MECHANISM

11. Remove the four (4) cup springs (C) (pinion bush). (Fig. 38). Lift the shifter and reverse clutch pistons. (Fig. 37). If necessary, tap the shifter with each hammer to remove.

CAUTION: The reverse clutch pressure plate may stick permanently to the reverse clutch piston. To avoid damage, prevent pressure plate from dropping.

12. Force compressed air into reverse clutch cylinder while holding piston, as shown in (Fig. 34) and piston will pop up out of reverse clutch cylinder.

13. Remove cooling rings as shown in (Figs. 34 and 34).

REMOVAL OF THROTTLE MECHANISM, REVERSE CLUTCH PRESSURE PLATE, FORWARD CLUTCH SPRINGS, FORWARD PISTON AND CLUTCH PLATE

14. Throttle rod can now be lifted from position shown in (Fig. 36).

15. Remove clutch pressure plate shown in (Fig. 32), and then lift out the remaining clutch piston (Fig. 32).

16. The reverse (R) pressure piston springs and the three (3) dwell pins can now be removed. (Fig. 33).

DISASSEMBLY OF DRIVE GEAR AND CLUTCH MECHANISM

17. Strip the exposed inner end of the input gear and lift straighten out drive gear and clutch assembly pins nearly 1/8" out of opening in front. (Fig. 39).

18. Remove thrust washer located between drive gear and plate/shaft carrier. (Fig. 39).

19. Slide drive gear and clutch assembly on shaft/shaft carrier and remove the forced & external snap rings to fully liberate from the drive gear and clutch cylinder. (Figs. 47 and 48). Be sure, push drive gear to rear beyond where the snap rings are retained.

20. While holding the ring gear, tap the front end of the drive gear with soft hammer. The drive gear and forward clutch hub assembly will pass through the ring gear and forward clutch assembly to come out of the rear end of the ring gear. (Fig. 41).

DISASSEMBLY OF FORWARD CLUTCH

21. Remove bearing from clutch cylinder by tapping with soft blunt tool.

22. Remove ring gear snap ring. (Fig. 38).

23. While holding ring gear, tap with soft blunt tool to expand them at forward clutch cylinder inside of ring gear. Forward clutch cylinder will move forward to disassemble out of front of ring gear. After done, tap the clutch spring and the clutch spring snap ring, all parts of the forward clutch can be disassembled as shown in (Figs. 29, 30, 31, 32 & 33).

24. Piston can be removed from forward clutch cylinder as position in (Fig. 36) by applying compressed air to clutch cylinder through one of three (3) holes in inside diameter of forward clutch cylinder, while other holes are blocked.



Fig. 39. (Continued by) Robert Fitch
From The Author

26. Remove forward clutch axling rings, as shown in (Figs. 26 & 27).

REMOVAL OF DRIVE SHAFT AND SUB- PULLEY ASSEMBLY FROM TRANS- MISSION CASE

28. Remove main shafts and shown in (Fig. 28).
29. Using bearing puller, pull output from output shaft.
30. Remove six (6) hex head bolts and lockwashers, (Fig. 29).
31. Remove bearing retainer and gasket.

REMOVAL OF REAR BEARING

NOTE: The following paragraphs (32 & 33) describe alternate methods of removing the rear bearing. Either method is equally desirable.

32. Using bearing puller, grasp bearing by exposed portion in outside dia. nut and gently pull bearing free rear, (Fig. 32).



Fig. 32. Removing bearing from rear

33. Place transmission, with front face down, on clean ground. Using available tool, press down on exposed end of output shaft until shaft is free of bearing inside diameter. Protect pinion cage and output shaft from damage from fall during this operation.

REASSEMBLY PRECAUTIONS

The following list contains a number of assembly problems which in its help requires special attention during the reassembly of the direct drive transmission. The subsection below includes the locations in the manual where lubrication and instructions are available on their important assembly features.

1. Installation of proper pinion cage and output shaft assembly in transmission cases without bushings (Page 31, Paragraphs 10 & 11).
2. Lubrication of the proper clutch spring wear ring. (Page 21, Paragraph 22).
3. Lubrication of the proper ring gear wear ring. (Page 25, Paragraph 10).
4. Installation of the proper retainer

wear ring. (Page 27, Paragraphs 10 and 11).

5. Installation of adaptors on transmission case should follow the procedure outlined. (Page 31, Paragraph 13). For tightening the capscrews, 10 bolts are not adequately tightened a small amount. Damage can result in the pinion bearing and its input shaft area.
6. Protection of pump seal during assembly of pump assembly over input drive gear. (Page 34, Paragraph 10).
7. Mounting pump to correspond to the engine rotation. (Page 35, Paragraph 10).
8. Check input shaft to insure that it rotates freely when turned by hand after transmission is mounted. (Page 35, Paragraph 10).

INSPECTION AND GENERAL INSTRUCTIONS

1. Cleanliness is absolutely necessary during assembly to insure proper functioning of transmission. Transmission case passages should always be clean when removed to allow for thorough cleaning. When available, use compressed air to dry parts before they are assembled. Do not wipe parts with rags to clean or dry them as lint from the cloth may cause serious valve action.
2. Inspect all parts for damage or wear. Replace defective parts.
3. All gaskets, oil seals and rubber sealing rings should be replaced except in relatively new units. Judgment should then be exercised as to the need for replacing these parts.
4. Oil seals and bearings are best installed by using an oil seal press, suitable fixture, and tools to properly align parts being assembled. Hammering seals and bearings into position can severely damage parts.
5. Automatic Transmission Fluid Type "D" or type "B" should be used in lubricating parts as they are assembled. Petroleum jelly may be used in gaskets or other parts that must be held in position during assembly. All rubber parts will slide more freely if lubricated.
6. Tighten all bolts and screws evenly to the recommended torque, (see page 58).

ASSEMBLY OF TRANSMISSION

ASSEMBLING OIL SEAL IN BEARING RETAINER

1. Separate rubber lip of seal for o-ring, before an intimate condition of rubber lip material.
2. Place front face of bearing retainer on work surface. Apply a suitable sealant to the outside diameter of seal before installing squarely

into bore of bearing with seal lip positioned as shown in (Fig. 16). Caution should be observed to insure that too much sealant is not used.

3. Using either press and suitable tool, as shown in (Fig. 17), press the oil seal into the bearing retainer until the rear face of the oil seal is flush with the rear face of the bearing retainer.



Fig. 16 Assembling oil seal



Fig. 17 Pressing oil seal in retainer



Fig. 14. Installing oil baffle.

INSTALLATION OF THE SHAFT IN THE TRANSMISSION CASE

1. Place oil baffle inside transmission case with correct position before cast spherical bearing in case as shown in (Fig. 14).
2. Position front end of baffle so that center of baffle rests on top of the base at front center of transmission case and the curved down corner of oil baffle are located below the cast spherical bearing at the front of transmission case. Snap baffle into position by hooking up an screw at position as shown the two large holes are located directly on the spherical bearing at rear of transmission case as shown in (Fig. 14).



Fig. 15. Baffle properly installed.



Fig. 16. Pinion, Input and Output Shaft Assembly in Place in Input Case.

INSTALLATION OF PINION CASE AND OUTPUT SHAFT ASSEMBLY IN THE TRANSMISSION CASE

2. When the pinion cage and output shaft assembly on a 5 inch diameter by 2-1/8 inch long assembly tool, which is turn is mounted on an other screw, as indicated in (Fig. 16).
- NOTE: If the transmission case does not have bronze bearings for the output shaft journal, use only the output shaft of the design with these will give you as shown in (Fig. 17). See page 45 paragraphs 10 & 11, for further information.
3. Place the transmission case over the pinion cage and output shaft assembly.



Fig. 17. Input and Output Shaft Pinion Case.



Fig. 20. Install oil seal and oil seal retainer. Oil seal and retainer are shown in place.



Fig. 21. Rear bearing shown in place.

14. In an intermediate case, remove the oil seal and oil seal retainer which is supporting assembly tool (Fig. 20).
15. Inspect the bearing bore for parallel, hole dies or burrs.
16. Inspect the rear bearing for scoring or damaged balls and races and for loose or cracked ball retainer. Replace the bearing with a new part if damage is detected.
17. Inspect the bearing for presence of dirt. If dirt is present, wash bearing with clean and lubricate with automatic transmission fluid, type "M", until it is clean. Before assembly.

18. With the grease on the outside diameter of the bearing located toward the rear of the transmission, as shown in (Fig. 21), place the bearing over the protruding output shaft and firmly in the bearing bore.
19. Using an assembly tool designed to press evenly on the bearing outer and inner races, press bearing from seal toward output shaft or rear shaft (Fig. 21).
20. Place bearing retainer gasket on rear of transmission case as shown in (Fig. 22). Gasket may be coated with petroleum jelly for easier assembly.
21. Place bearing retainer in place on rear of case as shown in (Fig. 23).



Fig. 22. Bearing assembly tool placed on front of oil seal.



Fig. 23. Bearing bearing shown in place.



Fig. 16. Detail of bearing bracket on front side of pump.
Install via the U-bolts fasteners and via the T/34-14 hex head bolts; tighten bolts to a torque of 42-55 pounds-feet.

11. Inspect, and lubricate the lub. disc on the rear coupling which runs in contact with the rubber lip of oil seal. If this surface is scratched or scored, replace the part with a new piece to prevent seal lip damage and subsequent oil leakage.
12. After lubricating the splined portion of coupling, assemble the splined coupling into the external splined portion of the output shaft. Make the coupling has been aligned exactly on the output shaft and hand assembly has proceeded as far as possible, place a suitable tool on the coupling, (Fig. 17), and gently press the coupling with other



Fig. 17. Pressing gear housing in place



Fig. 18. Top of planetary housing.
gears until contact with the bearing inner race is made.

13. Assemble shaft which run in place on output shaft's and tighten to pre-specified torque of 100 to 200 pounds-feet. This should bring inner race of bearing axially in contact with the shoulder on output shaft and eliminate any detectable end play in the coupling with output shaft combination, (Fig. 19).

ASSEMBLY OF THE FORWARD CLUTCH OVER THE RING GEAR

14. When the ring gear is in close contact with the internal teeth up, is shown in Fig. 20.
15. Remove all dirt and solid particles from the shoulder inside the gear formed by the top of the internal helical gear, (Fig. 21).



Fig. 20. Installing Output Pressure Ring

[illegible]

© 1997 by The McGraw-Hill Companies, Inc. All rights reserved. Printed in the United States of America. This book is printed on acid-free paper.

... and the ...

[illegible]

111. *Staphylococcus aureus* (Staph.) is a Gram-positive, spherical bacterium. It is a facultative anaerobe, meaning it can grow with or without oxygen. It is a common cause of skin infections, such as abscesses and boils, and is also responsible for food poisoning. It is highly resistant to many antibiotics and disinfectants.

11. With the camera wide of the subject, geting down, toward the dog's feet, as shown in Fig. 10. Slightly to the rear of the dog and upward in position to emphasize the change in the dog's position.

[illegible]



Fig. 26. Installing Clutch Bearing Ring

Insert an instruction card lubricate before assembly.

26. Install in forward clutch cylinder a well lubricated cooling ring. (Fig. 26). Lubricate entire forward clutch cylinder before commencing assembly.

27. After slipping the assembled forward clutch plates assembly on the assembled forward clutch cylinder, press the clutch plates into the forward clutch cylinder, as shown in Fig. 26. This is a hard assembly and should not require pushing or hammering as pressing or other means, damage to components when plates assembly is dropped in forward clutch cylinder.

28. Place the assembled parts, as assembled in stage 18 through 24 inclusive, on a suitable support which has been placed on an oil pan cover.



Fig. 28. Installing Gear Ring



Fig. 29. Installing Forward Clutch Plates

- (Fig. 27). Insert the clutch spring in the ring gear.

29. Place the parts assembled in stages 25 through 27 inclusive into the open top of the assembly described in step 28. (Fig. 27). Place a suitable assembly tool squarely on top of the forward clutch cylinder and press down with the other press until the forward clutch cylinder is fully seated on the snap ring and the groove for the snap ring is fully exposed. Check, by looking into end of ring gear, to be sure that the clutch spring bearing ring is properly assembled on the forward clutch press.

30. While maintaining load from other press, assemble ring gear snap ring. (Fig. 28). The ring slide in place to insure full seating of ring in groove.



Fig. 31. Pressing Forward Oil Seal into Ring Gear



Fig. 30 Assembling the snap ring

CARNING: Be sure you have the proper snap ring. The ring has **SNAP RING IS .071 IN. X .015 INCHES THICK AND HAS A FREE DIAMETER OF 1.75 - 1.76 INCHES.**

11. Place the forward clutch and ring gear assembly onto the shaft (see Fig. 31) including an air washer with the assembly supported on the face of the ring gear as shown in (Figure 32).
12. Place a suitable assembly tool in the air hole to apply force on the clutch pressure plate compressing the clutch plates and clutch pressure plate against the clutch snap ring. The gap between the clutch pressure plate and the shoulder of the snap ring gear in the ring gear can then be removed with a feeler gauge as shown in (Fig. 33).



Fig. 31 Pressing the forward clutch



Fig. 32 Assembling the snap ring

13. Install one, or more when needed, of the selective snap rings, as shown in (Fig. 34) to obtain a proper clutch plate clearance of .005-.010.

CARNING: Be sure the proper snap ring is used. The 'Selective Snap Ring' has a free diameter of **.005-.010** inches. These rings are available in thickness and are color coded as follows: Green-.010 to .015 inches thick; Orange-.015 to .020 inches thick; White-.020 to .030 inches thick.

ASSEMBLY OF FORWARD CLUTCH DISC AND SEALING RINGS ON DRIVE GEAR

14. Place the forward clutch hub as a suitable assembly placed on the air hole in the previous shown in (Fig. 35).
15. Assemble Woodruff key in the keyway provided on the drive gear, (Fig. 36).



Fig. 35 Pressing the forward clutch hub



Fig. 38. Installing Clutch Release Ring



Fig. 39. Sliding Ring Ring and Clutch Assembly to Drive Gear

36. Lubricate the outside diameter of the drive gear so that some thick grease flows into the forward clutch hub.

37. Install the drive gear and Woodruff key assembly into the forward clutch hub, being careful to align the Woodruff key with the mating grooves in the forward clutch hub (Fig. 41). Press the drive gear into the forward clutch hub until the gear "bottoms" on the face of the forward clutch hub and the gears for the ring ring is fully uncovered.

38. Insert the parts referred to in step 34 and install snap ring in the groove provided (Fig. 40). The ring after assembly with outside end to inner ball bearing in groove.

39. Install run in forward clutch sealing rings in grooves provided on drive gear (Fig. 43). After in-

stalling rings in groove, back side and rear rings to inner location of rotation.

ASSEMBLING DRIVE GEAR AND CLUTCH ASSEMBLY

40. With drive gear and clutch hub in assembly tool as shown in (Figs. 44 and 45), place ring gear and fasten clutch assembly over drive gear as shown in (Fig. 46).

41. Lower ring gear and clutch assembly until internal teeth of clutch plates begin to engage with on forward clutch hub. Rotate ring gear to align teeth of plates with teeth on clutch hub. Do not force ring gear, as damage to teeth on plates will result. When ring gear and clutch are in correct position, rear end of ring gear should be against the assembly tool or "block" with the rear thrust face of drive gear.



Fig. 40. Installing Forward Clutch Sealing Rings to Drive Gear



Fig. 41. Sliding Ring Ring and Clutch Assembly to Drive Gear



Fig. 39. Pressing front bearing in place

as shown in (Fig. 40). Do not reverse drive gear and clutch assembly from assembly stand as drive gear goes forward until steps 41, 42 and 43 are completed. As movement of the drive gear forward will result in the clutch plates bearing drive, engaged with clutch hub and mating rings moving out of position.



Fig. 40. Installing rear ring

INSTALLATION OF DRIVE GEAR AND CLUTCH ASSEMBLY, REVERSE CLUTCH SHAFT, AND REVERSE CLUTCH PHRONE/UM PLATE IN TRANSMISSION CASE

40. Place the gear assembly in steps 1 through 37 inside, on a smooth, clean surface in the opposite position indicated in (Fig. 40). In this position, the rear face of rear coupling will provide sufficient clearance to enable assembly to proceed.

41. Coat the drive gear shafts, bushes with petroleum jelly and assemble into pinion cage and output shaft assembly, as shown in (Fig. 41). Contact the output shaft(s) area have provided for rear of drive gear.

42. After lubricating the rear end of the drive gear and checking correct position of the thrust washer, insert the drive gear and clutch assembly into the case and pinion

41. Place aligned parts and assembly tool in place on shaft pins. Place bearing over protruding drive gear and upsertly into hole in front of forward clutch cylinders gear bore. Tap down with rubber mallet until bearing is fully seated on shoulder and snap ring groove in front of bearing are engaged (Fig. 40).

42. Install external snap ring on drive gear. (Fig. 42).

43. Install internal snap ring in clutch cylinder. (Fig. 43).



Fig. 41. Installing Snap Ring



Fig. 42. Inserting Ring Through Washer

shaft and output shaft assembly, (Fig. 10). Case and pump centering must be maintained at this point to prevent damage to the bearings when the next diameter of the drive gear enters the output shaft.

40. Install the twelve (12) pressure plate springs in the holes provided in the reverse clutch casing, (Fig. 11). The holes should be free from dirt and all springs should be firmly seated.
41. Fast the three (3) thrust pins with petroleum jelly and assemble them in the three (3) pressure pins in the reverse clutch casing, (Fig. 12). Assemble



Fig. 10 Installation of Input (1) Thrust Pins, Springs and Input (2) Thrust Pins



Fig. 11 Installing Three Thrust and Thrust Springs

in sequence when the thrust pin is firmly seated on end and into the groove, as far as pressure contact will permit.

42. Install one of the reverse clutch plates over the exposed tapered teeth of the ring gear. Install the outer clutch plate with the end shaped lug located as shown in (Figure 12) to obtain the proper spacing with reference to the springs. Install the second reverse clutch plate on top of the outer clutch plate and over the exposed tapered teeth of the ring gear.
43. Install the reverse clutch pressure plate with the twelve (12) holes in

the dovetailed position. Align the end slot in the pressure plate with the lugs and hole in the lower face of the transmission case, (Fig. 13). Since the twelve (12) pressure plate springs are not evenly spaced, the slot and oil hole alignment are required to locate the pressure plate with relation to the pressure plate springs, (Fig. 13). A properly assembled reverse pressure plate will appear as shown in (Fig. 13). If pressure plate does not drop down in position, approximately flush with transmission case front face, check the three (3) thrust pins for possible misalignment.



Fig. 12 Installing Reverse Thrust Plates



Fig. 14. Assembling the oil seal into the adapter hub.

13. Coat the oil seal with petroleum jelly and assemble, as shown in Fig. 15b.

ASSEMBLY OF REVERSE CLUTCH PISTON INTO ADAPTER

14. After attaching adapter for the following, place it in clean surface in position, shown in Fig. 15a.

(a) Clean inside bearing assembly, properly installed and free from damage.



Fig. 15. Assembling bearing ring.

- (b) Oil passages free from presence of dirt and obstruction.
- (c) Reverse clutch carrier outer wall, smooth clean surface free from scratches or burrs and coated generously with petroleum jelly.

Coat sealing ring with petroleum jelly and install in groove of adapter hub, as shown in Fig. 14.

15. After lubricating sealing ring with petroleum jelly, assemble in groove of reverse clutch piston, as shown in Fig. 16.



Fig. 16. Assembling bearing ring.

16. Remove inside diameter of reverse clutch piston for smooth clean surface free from scratches or burrs and coat generously with petroleum jelly.
17. Place the reverse clutch piston, as assembled in step 15, on the adapter, as assembled in step 13, Fig. 15c. Press down on reverse clutch piston while pulling it smooth, clean cam-driver blade around the tapered groove of the sealing ring. This will seat the chamfered bore in the adapter to compress the sealing ring into the groove in the outside diameter of the piston. Assembly can be completed by using hand pressure until driver has "bottomed" in reverse clutch carrier.

Equalize face of clutch plates should be fixed with adjuster surrounding surface on adapter when assembly is completed.

INSTALL OF ADAPTER AND CENTRAL CLUTCH PISTON INTO TRANSMISSION CASE

17. With parts assembled, in steps 1 through 16 inclusive, looking on the rear face of coupling, coat the engaged faces of the transmission case with petroleum jelly and assemble in place the central adapter gasket, (Fig. 11).



Fig. 11 Assembling Adapter and Central Clutch Piston into Case

18. With combined parts assembled in steps 14 through 16 inclusive, these parts assembled in steps 1 through 16 inclusive, as shown in Fig. 12. Wipe the oil below as indicated in Fig. 12. Then lower the central clutch piston and adapter assembly squarely into the input gear and transmission case.

19. When the shoulder on the rear of the adapter has entered the mating bore in the central clutch cavity, located in the front of the transmission case, and a check of the gap between case and adapter indicates the



Fig. 12 Assembling Adapter and Central Clutch Piston into Case

adapter is squarely in place, install the four 1/2" cap screws, as shown in Fig. 13. The adapter can now be pulled down equally, until contact with the case is made, by alternately tightening the cap screws a small amount and checking frequently for binding. When adapter is pulled down as far as possible, tighten the four 1/2" cap screws to 25 to 35 pounds foot torque.



Fig. 13 Sealing Adapter to Case

42. When used in assembly, lubricate the pump housing with the proper transmission oil and place as shown in (Fig. 41). Install lubricated drive pump gear with identification mark as shown in (Fig. 41).

Mounting Front Pump on Truck. REASON

44. Place parts assembled in steps 1 through 43 inclusive as shown in (Fig. 42), after disengaging the coupling from the fly and clutch. (Note).
45. Lubricate and install front pump gears, (Fig. 42).



Fig. 42 Assembling Pump Drive Gear

46. Install Wedgeoff bar, (Fig. 43).

(NOTE: Check (Fig. 43) to determine that proper bar and shaft are used).

47. Install the pump drive gear on the input shaft, with one of the Wedgeoff bar slots in drive gear mesh with the Wedgeoff bar on the input shaft, (Fig. 43).

(NOTE: The two pump gears should be assembled so that the same gear faces are mated with the machined face of the pump housing as found at disassembly. Marks should have been applied at disassembly to insure proper reassembly, (Page 14, paragraph 41).



Fig. 43 Installing Pump Drive Gear by
use Wedgeoff Bar

48. Rotate the output portion of the input drive gear with a suitable tool to position the rubber lip on the seal during the assembly of the remaining front pump parts, (Fig. 43).
49. With the pump drive gear properly installed in the front pump housing, assemble the housing and pump drive gear squarely over the processing input shaft and assembly tool. A slight rotation of the pump housing and pump drive gear will allow engagement of pump gear teeth, (Fig. 44).



Fig. 44 Assembling Pump Gear



Fig. 49. Installation Markings for Pump.
Position Hole for Oil Seal Lubrication

10. Drive the pump mounting bolt holes and secure indicating direction of rotation to correspond with the direction of rotation required by the engine. (Fig. 50). If not installed in the proper rotation the pump will not produce oil pressure to operate the transmission when engine is started.

NOTE: WITH THE EXCEPTION OF THE 2.15:1 REDUCTION GEAR THE ORIENTATION OF THE PUMP ON THE TRANSMISSION MAY BE CHANGED FOR INSTALLATION ON ENGINES WITH ROTATION OPPOSITE TO THAT FOR WHICH THE TRANSMISSION



Fig. 50. Mounting Pump to Housing

WAS ORIGINALLY DESIGNED. THE DIRECTION OF ROTATION OF THE PUMP ON A 2.15:1 TRANSMISSION SHOULD MATCH WITH THE ORIGINAL FACTORY INSTALLATION AND MUST NOT BE CHANGED.

11. With the pump assembled squarely against the adapter and pump gaskets, and the seal assembly seal removed, install four (4) 3/16-18 hex head bolts. (Fig. 49). Tighten hex head bolts evenly in torque of 25-30 pounds-feet.
12. Check freedom of rotation of pump gears in pump housing by rotating the input shaft. If the pump will not rotate freely, disassemble the pump and check for foreign material.



Fig. 51. Package View of Valve and Spring Assembly

in the pump. Any dirt particles on the adapter face will also tend to work the pump when mounted on the adapter and cause it to seize.

ASSEMBLING VALVE AND SPRING ASSEMBLY

13. Gather the valve and spring assembly components, as shown in (Fig. 51), on a clean surface and note carefully the following:

- (a) The hollow portion of the pressure regulator valve forms the valve spring.



Fig. 38. Control valve assembly in position.

33) The valve spring assembly into the pressure regulator valve.

34) The concrete portion of the valve spring assembly assembly onto the valve spring.

35. After carefully checking the pressure regulator valve and the beam in the tapered and 45-degree cone connection valve for stem and beam, assemble all valve and spring components shown in (Fig. 37).

36. Place the assembled parts in a suitable assembly fixture, (Fig. 39). Turning handle of threaded plunger, compress the regulator valve spring until the groove for the stem 104 in the pressure regulator valve is fully engaged. Install cone ring shown in (Fig. 40). The 52 ring shown in (Fig. 41) should be installed in end of valve.

NOTE: The control valve assembly can also be assembled by using an valve gages with suitable scale, as shown in (Fig. 42).



Fig. 39. Installation of beam ring.

INSTALLATION OF THE VALVE AND SPRING ASSEMBLY IN THE TRANSMISSION CASE

37. Place parts assembled in steps 1 through 13 inclusive, on clean flat surface. From the opening provided high on the right-hand side of the transmission case, place the valve and spring assembly, threaded end pointing down, (Fig. 39). Then in a level assembly and is completed when the valve and spring assembly "bottoms" against the shoulder in the case bore.



Fig. 40. Concrete portion of valve and spring assembly.



Fig. 19 Assembly of Valve Cover



Fig. 20 Bolt Cover Assembled

19. To insure correct positioning of valve and master assembly of lower valve, 100%-10% water pump to valve with hexagon 1/4-16 inch hole in valve cover face of case as shown in (Fig. 19).

20. Assemble the valve cover gasket, valve cover, fasteners and iron head bolts as indicated in (Fig. 19). Torque iron head bolts to 8-11 pounds-feet.

ASSEMBLY OF SHIFT LEVER

21. Assemble shift lever and related parts in the order shown in (Fig. 19). Torque the hex nut 8 to 11 pounds-feet, (Fig. 19). Rotation of the valve and spring assembly through the forward, neutral and reverse positions should require no more than fingertip effort. If valve binds in rotation, remove and inspect.



Fig. 21 Assembly of Shift Lever and Related Parts



Fig. 22 Positioning Shift Lever in Housing

INSTALLATION OF OIL STRAINER ASSEMBLY AND OIL DRAIN PLUG INTO THROATLINE CASE

80. Assemble the oil strainer assembly, cooler line return leading and cooler return tube assembly in the order shown in (Fig. 76). The bottom end of the oil strainer assembly should be approximately 1/2 inch below the base of the case when the assembly is currently installed.

81. Tighten cooler line return and oil drain leading to recommended torque of 20 to 25 pounds feet.

INSTALLATION OF MISCELLANEOUS THROATLINE PARTS

82. Install the breather assembly as shown in (Fig. 78). Do not hammer on the top of the breather assembly illustrated as this will damage the sealing element. For installation of water pump breather assemblies see page 41, Paragraphs 1-4 a) for instructions.



Fig. 76 Installation of the Oil Strainer Assembly

83. Torque the breather assembly as shown in (Fig. 78) and tighten to a torque sufficient only to prevent oil leakage (approximately 20-25 pounds-feet).

84. Torque 1/8-28, 1/4-18 and 1/2-27 downed plugs, (Fig. 77) and torque to values indicated on page 36.



Fig. 78 Installation of Breather Assembly



Fig. 77 Torque Values of Downed Plugs

EXTRA EQUIPMENT

ASSEMBLY OF NEUTRAL SWITCH KIT

1. Remove three (3) hex head bolts, remove valve cover and gasket, as shown in (Fig. 11). Remove valve cover, gasket, hex head bolts and lockwashers.
2. Shift control lever into neutral position, see page 17 (Fig. 12). Remove gasket provided in neutral switch kit. Remove neutral switch cover, making sure no chips hang in/ on cover with slot "W" in valve, as

shown in (Fig. 13). Neutral switch can optionally be installed as shown in (Fig. 10).

3. Remove valve cover and neutral switch with neutral switch located between cam (2) and 1/4-20 bolts, as shown in (Fig. 14). Use the three (3) 1/4-20-7/8 inch long hex head bolts provided in neutral switch kit. Tighten hex head bolts to recommended torque of 8 to 11 pounds and install starter solenoid wires to switch.



Fig. 12 Neutral Switch Parts



Fig. 13 Neutral Switch Set in Cover



Fig. 14 Assembly of Neutral Switch



Fig. 15 Neutral Switch Correctly Secured

SPECIAL INFORMATION AND INSTRUCTIONS

MODEL 72C TRANSMISSIONS

NOTE: It may be found that in a Model 72C transmission assembly a number of components are very close to the description and illustrations presented in the preceding portion of this manual. This results from changes which have been made since the first introduction of this model. In this section the illustrations and description is presented for those features which are no longer incorporated in the current production models.

INSTALLATION OF OIL FILLER CAP ON THE OIL PUMP ASSEMBLY

1. Place oil filler cap and dipstick assembly in the oil filler tube provided on rear left side of transmission case. (Fig. 10). Push down on filler cap and dipstick until assembly bottoms on tube, then turn cap to right as far as cap screw permits.

INSTALLATION OF OIL STRAINER SCREENS AND OIL DRAIN PLUG INTO TRANSMISSION CASE

NOTE: The 72C transmission case, shown in



Fig. 10. Installation of oil filler cap and dipstick assembly.

is used a smaller screen landing with threads wider than the tapered drain plug threads are used. This installation with the 140001 cover screen landing. (Fig. 11), requires a copper washer part 12204200 to prevent leakage. Oil screen 111-6990 was also formerly used in this assembly, but has now been replaced with oil screen 72C-6990, which is fully interchangeable. The two landings are not interchangeable and the correct parts must be installed as illustrated in (Fig. 11) or (Fig. 12). These installations requiring the use of the parts in (Fig. 11) can be easily identified by the machined face on the case bore as indicated.

2. Assemble the oil screen assembly, screen gasket, and smaller screen line landing in the order shown in (Fig. 11). The end of the screen will be approximately 1/2 inch below the machined machined surface of the case, when inserted in the case to the full depth. Mount the screen gasket on the outer screen landing and tighten in the case.



Fig. 11. Installation of oil strainer screen and smaller case screen landing.

INSTALLATION OF BREASTER ASSEMBLY

3. In addition to the breaster assembly shown in (Fig. 11), other breaster assemblies will be found in use as illustrated in (Fig. 10) and (Fig. 11). These illustrations show: exactly the manner in which the breaster assemblies are installed.
4. The breaster in (Fig. 10) is supplied for those installations where a pressure type breaster replaces the breaster shown in (Fig. 10a). This breaster is used with an internally threaded backing which permits the use of the same before the installation of the standard breaster assembly.

ASSEMBLY OF FRONT PUMP

NOTE: The following instructions are for the assembly of the front pump with a backing plate, (Fig. 10). This pump can be used with either of the two different styles of backings, but it should normally be found assembled as the one shown in (Fig. 10). One of the various versions of the target shafts may be used with this pump, but the proper key must always be used with each shaft. See (Fig. 10) for comparison of the installation of the two pump assemblies and information on the other related parts.



Fig. 10 Installation of breaster assembly



Fig. 10a Installing breaster assembly



Fig. 10b Key fitting in front breaster





Abstract



© 2004 Blackwell Publishing Ltd *Journal of Internal Medicine* 255: 105–112



...and about 100,000 people are expected to attend the festival.

© 2000 Blackwell Science Ltd
Journal of Internal Medicine 247: 391–397

[illegible]

1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 2679, 2680, 26

© 2004 Blackwell Publishing Ltd, *Journal of Internal Medicine* 255: 103–110

1. **Introduction**
 2. **Background**
 3. **Methodology**
 4. **Results**
 5. **Conclusion**
 6. **References**
 7. **Appendix**
 8. **Index**
 9. **Table of Contents**
 10. **Figure 1**
 11. **Figure 2**
 12. **Figure 3**
 13. **Figure 4**
 14. **Figure 5**
 15. **Figure 6**
 16. **Figure 7**
 17. **Figure 8**
 18. **Figure 9**
 19. **Figure 10**
 20. **Figure 11**
 21. **Figure 12**
 22. **Figure 13**
 23. **Figure 14**
 24. **Figure 15**
 25. **Figure 16**
 26. **Figure 17**
 27. **Figure 18**
 28. **Figure 19**
 29. **Figure 20**
 30. **Figure 21**
 31. **Figure 22**
 32. **Figure 23**
 33. **Figure 24**
 34. **Figure 25**
 35. **Figure 26**
 36. **Figure 27**
 37. **Figure 28**
 38. **Figure 29**
 39. **Figure 30**
 40. **Figure 31**
 41. **Figure 32**
 42. **Figure 33**
 43. **Figure 34**
 44. **Figure 35**
 45. **Figure 36**
 46. **Figure 37**
 47. **Figure 38**
 48. **Figure 39**
 49. **Figure 40**
 50. **Figure 41**
 51. **Figure 42**
 52. **Figure 43**
 53. **Figure 44**
 54. **Figure 45**
 55. **Figure 46**
 56. **Figure 47**
 57. **Figure 48**
 58. **Figure 49**
 59. **Figure 50**
 60. **Figure 51**
 61. **Figure 52**
 62. **Figure 53**
 63. **Figure 54**
 64. **Figure 55**
 65. **Figure 56**
 66. **Figure 57**
 67. **Figure 58**
 68. **Figure 59**
 69. **Figure 60**
 70. **Figure 61**
 71. **Figure 62**
 72. **Figure 63**
 73. **Figure 64**
 74. **Figure 65**
 75. **Figure 66**
 76. **Figure 67**
 77. **Figure 68**
 78. **Figure 69**
 79. **Figure 70**
 80. **Figure 71**
 81. **Figure 72**
 82. **Figure 73**
 83. **Figure 74**
 84. **Figure 75**
 85. **Figure 76**
 86. **Figure 77**
 87. **Figure 78**
 88. **Figure 79**
 89. **Figure 80**
 90. **Figure 81**
 91. **Figure 82**
 92. **Figure 83**
 93. **Figure 84**
 94. **Figure 85**
 95. **Figure 86**
 96. **Figure 87**
 97. **Figure 88**
 98. **Figure 89**
 99. **Figure 90**
 100. **Figure 91**
 101. **Figure 92**
 102. **Figure 93**
 103. **Figure 94**
 104. **Figure 95**
 105. **Figure 96**
 106. **Figure 97**
 107. **Figure 98**
 108. **Figure 99**
 109. **Figure 100**
 110. **Figure 101**
 111. **Figure 102**
 112. **Figure 103**
 113. **Figure 104**
 114. **Figure 105**
 115. **Figure 106**
 116. **Figure 107**
 117. **Figure 108**
 118. **Figure 109**
 119. **Figure 110**
 120. **Figure 111**
 121. **Figure 112**
 122. **Figure 113**
 123. **Figure 114**
 124. **Figure 115**
 125. **Figure 116**
 126. **Figure 117**
 127. **Figure 118**
 128. **Figure 119**
 129. **Figure 120**
 130. **Figure 121**
 131. **Figure 122**
 132. **Figure 123**
 133. **Figure 124**
 134. **Figure 125**
 135. **Figure 126**
 136. **Figure 127**
 137. **Figure 128**
 138. **Figure 129**
 139. **Figure 130**
 140. **Figure 131**
 141. **Figure 132**
 142. **Figure 133**
 143. **Figure 134**
 144. **Figure 135**
 145. **Figure 136**
 146. **Figure 137**
 147. **Figure 138**
 148. **Figure 139**
 149. **Figure 140**
 150. **Figure 141**
 151. **Figure 142**
 152. **Figure 143**
 153. **Figure 144**
 154. **Figure 145**
 155. **Figure 146**
 156. **Figure 147**
 157. **Figure 148**
 158. **Figure 149**
 159. **Figure 150**
 160. **Figure 151**
 161. **Figure 152**
 162. **Figure 153**
 163. **Figure 154**
 164. **Figure 155**
 165. **Figure 156**
 166. **Figure 157**
 167. **Figure 158**
 168. **Figure 159**
 169. **Figure 160**
 170. **Figure 161**
 171. **Figure 162**
 172. **Figure 163**
 173. **Figure 164**
 174. **Figure 165**
 175. **Figure 166**
 176. **Figure 167**
 177. **Figure 168**
 178. **Figure 169**
 179. **Figure 170**
 180. **Figure 171**
 181. **Figure 172**
 182. **Figure 173**
 183. **Figure 174**
 184. **Figure 175**
 185. **Figure 176**
 186. **Figure 177**
 187. **Figure 178**
 188. **Figure 179**
 189. **Figure 180**
 190. **Figure 181**
 191. **Figure 182**
 192. **Figure 183**
 193. **Figure 184**
 194. **Figure 185**
 195. **Figure 186**
 196. **Figure 187**
 197. **Figure 188**
 198. **Figure 189**
 199. **Figure 190**
 200. **Figure 191**
 201. **Figure 192**
 202. **Figure 193**
 203. **Figure 194**
 204. **Figure 195**
 205. **Figure 196**
 206. **Figure 197**
 207. **Figure 198**
 208. **Figure 199**
 209. **Figure 200**
 210. **Figure 201**
 211. **Figure 202**
 212. **Figure 203**
 213. **Figure 204**
 214. **Figure 205**
 215. **Figure 206**
 216. **Figure 207**
 217. **Figure 208**

[Home](#)
[About Us](#)
[Contact Us](#)
[Privacy Policy](#)
[Terms of Service](#)

Copyright © 2004 John Wiley & Sons, Ltd.

© 2004 Blackwell Publishing Ltd, *Journal of Internal Medicine* 255: 103–110

1. The first step is to identify the problem. In this case, the problem is that the company is not meeting its sales targets.

[illegible]

© 2006 Blackwell Publishing Ltd *Journal of Internal Medicine* 260: 459–467

1. The first step is to identify the problem. This involves understanding the symptoms and the context in which they are occurring.

© 2006 The Authors
Journal compilation © 2006 Blackwell Publishing Ltd





Fig. 10 Elimination of markings for use T1-440 and T1X-440 of T1-440 adapter



Fig. 11 Elimination of markings for use T1-440 and T1X-440 of T1-440 adapter



Fig. 12 Buffing Feed Pump Assembly

NOTE: The location of the markings on the T1-440 pump bearing identifying the orientation of the pump assembly on the adapter for right or left hand rotation will vary depending upon which pump assemblies and adapters are used.

The motor pump assembly with backing plate, identified by the rib on the pump bearing, will be properly mounted when the marking on the pump bearing appears as shown (a)Fig. 10), when mounted on the T1-440 adapter, (Fig. 10). If the pump were mounted on the new adapter T1X-4, (Fig. 10), the pump markings would be identical to those illustrated for the new T1X-440 pump assembly in (Fig. 10).

The slider pump assembly with backing plate, identified by the absence of the rib on the T1-440 pump bearing, would appear as illustrated in (Fig. 10) when mounted on the old T1-440 adapter (Fig. 10). This slider pump assembly with backing plate could also be mounted on the new T1X-4 adapter (Fig. 10), but this has not been illustrated as no original factory installations were made in this manner.

15. With feed pump assembly mating correctly on gasket and seal assembly and correct, install four (4) 1/8" long hex head bolts, (Fig. 11). Tighten hex head bolts evenly to torque of 11 to 12 pounds-feet.

ELIMINATION OF REGULATOR VALVE 0122

16. New pressure regulator valves (PA-101) have a relief on the outer dia. cover on the closed end for the elimination of regulator valve 0122. (Fig. 10). If a transmission should have a valve from and contain a T1-440 pressure regulator valve which does not have the relief, the valve should be replaced or replaced as illustrated.

11. The two methods of sealing the end of the drive gear are illustrated in Figs. 100, 101. Detail 100 illustrates the method now used and shows 7/8" the method formerly used. The two drive gear assemblies, varying only in the method of sealing the end of the shaft, are fully interchangeable.

FINISH CASE AND OUTPUT SHAFT ASSEMBLY

12. Finish case and output shaft assembly has been supplied with three oil grooves around the shaft diameter as shown in Fig. 102. Two shafts can be used to replace any shafts. However, shafts without the grooves must not be used with those forward and reverse transmission cases supplied without the 11,000 bushings.

FORWARD AND REVERSE CASE THROTTLE POSITION CASE AND BUSHING ASSEMBLY

13. Two versions of the transmission case have been supplied, one includes bronze bushings for the output shaft journal, the other is designed for use without the bushings. These two versions of the transmission case are completely interchangeable, except that the case without bushings cannot be used with the output shaft transmission shafts as now have the oil grooves (Fig. 100). Information regarding the service replacement of case bushings can be found on page 12, (Fig. 100). It is become necessary to replace a case of the design without bushings because of worn journals, it can be returned to your engine supplier. He can return the case to Detroit Diesel for inspection and certification of bushings and can furnish information concerning the cost of this service.

SHAFT CAPSCREW

14. The 5/16-11x1-1/8 hex socket cap screw (120243) formerly used to fasten the adapter to the transmission case has now been replaced with a torque clip-point cap screw (12011) which has better locking characteristics. The two types are completely interchangeable.



Fig. 99 Replacement of Output Shaft Seal



Fig. 100 Removal of Oil Seal and Oil Installation



Fig. 101 Removal of Output Shaft Assembly from the Case

SPECIAL INFORMATION AND INSTRUCTIONS MODEL 72 TRANSMISSIONS

NOTE: Except for the discussions and illustrations on the features included in this section all other information concerning the Model 72 transmissions can be found in preceding sections of the manual concerning information for the assembly or disassembly of the Model 72C transmission, or in the special supplementary section for these transmissions, pages 44 to 46.

INSTALLATION OF BREATHER ASSEMBLY

1. Assemble the cover-to-top bearing assembly as shown in (Fig. 181).

ASSEMBLY OF FRONT PUMP

1. The pump assembly for the Model 72 transmissions 721-1A20 contains a difference seal when the pump assembly with bearing plate for the Model 72C 721-1A20. These seals identical in all other respects. Therefore, when assembling the front pump assembly 71-461 follow the information in paragraphs 5-251 page 41 to 44, with the exception that the seal should be pressed onto the pump housing until front face of seal is 1/8 inch above front face of pump housing. (Fig. 182).

2. On some early production Model 72 transmissions the overall height of

the pump housing bearing faces may, need 1.750 inches instead of 1.500 on all other later pump assemblies. For any pump housing having the 1.750 inch dimension, assemble the seal 1/8 inch below appropriate pump face.

SELECTION OF REVERSE CLUTCH PLATE

1. On early Model 72 transmissions the main casting depth for the reverse clutch plate measured only .710-.720. These units require replacement clutch plate different from those specified for present production transmissions and should be ordered as specified below:

TYPE	SIZE	PART NAME	QTY.
1A	72-46	REAR. 72C	1
1B	72-46	REVERSE CLUTCH PLATE	1
1C	72-74	REAR REVERSE CLUTCH PLATE	1

DRIVE GEAR & PILE ASSEMBLY

1. The drive gear assembly has a 24-32-pinion input drive rollers. See other instructions on page 45, paragraph 575.



Fig. 181 Installation of breather assembly



Fig. 182 Pressing fit seal



Fig. 10. Model 70 Shift Lever Assembly

REMOVAL OF SHIFT LEVER

6. For removal of shift lever see page 10, paragraph 7c. The assembly procedure is the same for the Model 70 Transmission as that described and illustrated for the Model 70L. Although the present shift lever (11-0004) (Fig. 10), can be substituted for the lever shown in (Fig. 10L), it would change the detail of the control linkage for shifts between "Neutral" and "Forward" positions, see (Fig. 12 and Fig. 10L).

SELECTION OF OTHER SHIFT COUPLING

7. Early Model 70 transmissions used a smaller diameter coupling (11-0001) than the present coupling (11-0004). Make the correct part to replace the one used on your transmission. This will avoid any installation problem concerning the mating part. Coupling-Bear Ball (11-0001) which would arise from these difference in size will be used for assembly. See parts list, page 12, for additional information.


COOLER RETURN TO TRANSMISSION

8. On the Model 70 transmissions it is now recommended that the cooler oil flow be returned to the transmission case as shown in (Fig. 11). Transmissions with the cooler flow entering in a system other than that now recommended need not be changed. However, the arrangement now recommended conforms to practices followed on other tanks, minimizes installation and permits better control of the cooler return oil flow to the pump section.

NOTE: If cooler return flow is changed to the new location be sure that the oil cooler installed is similar to the one illustrated in (Fig. 10L). The oil cooler assembly with one end secured would block the flow of the cooler return oil.

TORQUE SPECIFICATIONS

PART NUMBER	DESCRIPTION	APPLICATION	TORQUE LBS.-FT.
179422	5/16-18 x 1-1/2 HEX HEAD BOLT	PUMP TO ADAPTER	17-22
4901	3/8-18 x 1-1/4 12 POINT CAPSCREW	ADAPTER TO CASE	27-37
119193	1/4-28 x 1/8 HEX HEAD BOLT	VALVE COVER TO CASE	8-11
119129	5/16-24 NUT	SHOFT LEVER TO PULVE	8-11
412792	5/16-14 x 1-1/8 HEX HEAD BOLT	BURNING RETAINER TO CASE	27-32
41108	1-28 NUT	OUTPUT SHAFT NUT	140-200
44038	3/4-18 BURNING	COOLER RETURN TO CASE	21-23
444687	1/8-27 CROSSH. PIPE PLUS	CASE	7-12
444687 444687 OPT'L.	1/4-18 CROSSH. PIPE PLUS	ADAPTER	11-20
444688	3/8-28 CROSSH. PIPE PLUS	CASE	17-27
75-4095	3/4-24 PIPE PLUS	SERVICE SH'T. INTO CASE	18-19



The assembly and drawings shown on this page are included as illustrations for those tools may be made. They will provide assistance in assembling and disassembling the transmission and their functions may be performed by the substitution of other designs or pro-

cedures. However, the use of the will pump assembly tool, or other means of protecting the seal lip, is a necessity.

The drawings are provided as a reference.

NOTE: GEAR CASE NOT MANUFACTURED OR BUILT, ANY OF THE TOOLS ILLUSTRATED.